

Autodesk[®] Revit Live

BEST PRACTICES FOR PREPARING AND EXPORTING REVIT MODELS FOR REVIT LIVE

Contents

- 1 What is Revit Live?
- 2 Material Libraries
- 3 Creating Custom Materials
- 4 Custom Texture Mapping
- 5 Modifying Structural Materials
- 6 Modifying Family Materials
- 7 Global Parameters
- 8 Lighting
- 9 Exporting from Revit to Revit Live
- 10 Viewing Models in VR
- 11 Conclusion

What is Revit Live?



Overview

Autodesk Revit Live is a cloud service that enables architects to turn their Revit and Revit LT models into an immersive experience in one click to help them understand, explore, and share their designs.

In this guide, we'll share best practices on how to properly make the most of your experience with Revit Live by showing you how to optimize material and lighting usage in your Revit model.

So, let's begin:

Step 1 - Start by prepping your Revit model with all the desired materials

Step 2 - Upload your Revit model to the cloud service via the Revit Live plug-in for Revit

Step 3 - Download and customize your Revit Live scene with a variety of visual options

Step 4 - Present your design using a variety of built-in navigation and interactive features such as virtual reality




CHAPTER 1

Material Libraries

CHAPTER 2

By default, Revit comes with two material libraries, if selected, during your initial Revit installation. These libraries include the Autodesk Materials and the AEC Materials. To access these libraries in Revit, navigate to Materials under the Manage tab in the main ribbon.



The upper list of materials includes all the materials that exist or were created specific to the current project, while the lower portion displays the external loaded material libraries.

Material Libraries


Selecting the drop down shown above allows users to navigate between the loaded material libraries. Once a desired material is located, it is added to the active project by double-clicking the material's name. We now have the ability to modify the default material attributes using the menu on the left.

	Material Browser - 0-PE_M	at 1		? ×
	Search		٩	Identity Graphics Appearance +
	Project Materials: Wood	*>		▼ Shading
	Name		÷	Use Render Appearance
				Color RGB 0 0 0
	Pine	Transparency 0		
	Walnut			▼ Surface Pattern
				Pattern <none></none>
	Wood - Teknion -	DX - Java Bean	*	Color RGB 0 0 0
	Autodesk Mat	erials v		Alignment Texture Alignment
Favorites		Name	40	
Autodesk Materials	erials	ABS Plastic		▼ Cut Pattern
				Pattern <none></none>
		Acetal Resin, Black		Color RGB 0 0 0
		Acetal Resin, White		
		Acoustic Ceiling Tile 24 x 24		
		Acoustic Ceiling Tile 24 x 48	Ψ	
	📑 • 🗣 • 🚍		~<	4 (
				OK Cancel Apply

Creating Custom Materials

Capture design intent using custom materials

As shown in the previous section, Revit gives us a series of materials. But what if the design calls for something more specialized? You have the ability to use all of the existing materials as a template for creating your own custom material. In this example, we will modify the default glass material to have a colored tint of our choice.



Creating Custom Materials

CHAPTER 3

Navigating to the Glazing drop-down menu, we notice an option for color. By changing this option from clear to custom, we can select the color of our choice. By checking the tint option below, we can further control how dark the glass becomes.

Material Browser - Glas	55					?	×
Search		٩	Identity Graphics	Appearance Physical The	ermal		
Project Materials: All	•>		Clear			0	10
Name		^		-			
EIFS, Exterior	Insulation			12			
Glass							
Glass, Clear G	ilazing		▼ Information				
			Name	Clear			
Autodesk I	Materials 🔹		Description	Glazing material.			
▶ Home	Name	*	Keywords	glass, glazing, window, clear, smooth, materials			
			▼ Glazing				
	ABS Plastic		Color Custom Color	or Custom			*
	Acetal Resin, Black			RGB 255 255 0			•
	Accessive and a second		Reflectance		15		
	Acetal Resin, White		Sheets of Glass		2		
			▼ ✓ Tint				
	Acoustic Ceiling Tile 24 x 24		Tint Color	RGB 191 191 191			
	Acoustic Ceiling Tile 24 x 48	¥					
📴 • 🚇 • 🗏		~~					
					OK Cance		Apply

To prevent any confusion, you can also rename your new material under the Identity tab. This tab contains all the basic descriptive information for the material. Click Apply to update material changes in the model.

Creating Custom Materials

Let's look at another example using a different material with different attributes. This time, we will create a custom wall paint. We start out by adding a generic white paint from the external AEC Materials to the Project Materials. Next, navigate to the Appearance tab on the left and observe the various attributes. For this material, we have Color, Finish, and Application attributes.

Material Browser - Paint					?	×
paint		×	Identity Graphi	cs Appearance +		
Project Materials: All 💌			Cool White			6
Search results for "paint"						
Name		A				
Gypsum Wall Boar	d					
Paint						
			▼ Information			
Parking Stripe		¥				
Search Result AEC	Materials 🔹		Description	Paint material for interiors.		
▼ Search Result	Name	A	Keywords	paint, white, cool, glossy, interior, wall, materials		
▼ 🛄 Autodesk Ma 🕆	Metal, Paint Finish, White, Matte		▼ Wall Paint			
Insulation Metal	T BE		Color	RGB 242 242 255		-
Plaster	Metal, Powder Coated, White		Finish	h Gloss		*
Plastic			Application	Brush		*
AEC Materials	Paint		▶ Tint			
Metal	Polystyrene, Expanded					
PlasterPlastic	Rigid insulation	*				
🔄 • 🚭 • 🚍		~~				
				OK	Cancel A	Apply

Let's modify these attributes for a custom variation. You may notice that we have additional information attributes above the options for Wall Paint. This information is different from the information under the Identity tab and is specific to just the appearance menu we are currently in, not the overall material.

Creating Custom Materials


Change the color of the paint to the desired RGB value. Choose a finish that will affect how the material renders when in contact with various lighting sources. Now, choose an application that controls how the paint will be applied to the given surface. Remember to rename your new material under the Identity tab.

Material Browser - Paint					?	×	
paint		×	Identity Graphic	cs Appearance +			
Project Materials: All 🔻			Bright Orang	je		· D	
Search results for "paint"							
Name Gypsum Wall Board				L.			
			▼ Information				
Parking Stripe		-		Bright Orange			
Search Result 🔹 AEC Mate	erials 🔹		Description	Paint material for interiors.			
▼ Search Result	Name	A	Keywords	paint, orange, bright, semi-glossy, interior, wall, materials			
✓ Autodesk Ma Autodesk Ma ✓ Insulation ✓ Metal	Metal, Paint Finish, White, Matte		▼ Wall Paint Color		•		
 Plaster Plastic 	Metal, Powder Coated, White	n	Finish Application	Semi-gloss Roller		•	
AEC Materials	Paint		▶ □ Tint				
T Misc	Misc Polystyrene, Expanded						
Te Plastic	Rigid insulation	-					
📑 • 🚇 • 🚍		~~					
				OK Cance	A	Apply	

Custom Texture Mapping

Creating materials with custom texture maps

What is a texture map? A texture map is essentially a 2D image that is wrapped around a 3D object. A simple example of this is the default brick material in Revit. It would be unnecessary to model every single brick and grout, so we apply a texture map from an image displaying a series of bricks. In this example, we will walk through creating a simple custom stone material using an image we received from a manufacturer.




When creating a new material, you always have the option of starting from the default material template, which essentially represents a completely blank material. Although this may often be the best practice, sometimes it makes more sense to select a similar existing material and make a modified copy. One thing to note about this approach is that physical or thermal metadata may no longer be accurate when we begin to modify certain attributes that can affect other internal calculations or analyses. In this example, we will create a new instance of brick so we can use one of the existing brick types as a starting point, making sure our physical and thermal properties are accurate based on the new type.

Custom Texture Mapping


CHAPTER 4


As you can see on the previous page, we have loaded a common brick material into the project Material Library as our starting point. Under the Appearance tab and under the Masonry drop down menu, you'll find an Image attribute. This is where the texture map is loaded. By selecting the drop down arrow and navigating down to Load Image, we are able to access the images properties.



Custom Texture Mapping

By selecting the map source, we can replace the original map with a map of our own. Once loaded, there are a series of options to control how the map is positioned, scaled, and tiled that can be adjusted to meet your specific needs. When the map is ready to be loaded, select Done at the bottom. Finally, it is also worth noting that you can modify how the map gets applied to a surface, depending on the shape as shown below.





Modifying Structural Materials

Changing the physical appearance of structural materials

Now that we have gone through how to create custom materials and apply custom maps, let's take a look at how to apply these materials to an existing structural element. Maybe we want to apply our new brick material to an existing brick wall. To do this, open up the Type Properties for the wall and observe the material under the Materials and Finishes section, which displays a grayed out Structural Material. This means we cannot directly change the material here.

pe Propert	ies			
Family:	System Family: Basic Wall		~	Load
Type:	Generic - 4* Brick		~	Duplicate
			[Rename
Type Param	neters			
		Parameter	Value	=
Construc				\$
Structure			Edit	
	at Inserts		Do not wrap	
Wrapping	at Ends		None 0' 4"	
Width				
Function			Exterior	
Graphics				*
	ale Fill Pattern		Diagonal up	
	ale Fill Color		Black	
	and Finishes			*
Structural	Material		Brick, Common	
Analytica	I Properties			\$
Heat Tran	sfer Coefficient (U)	Structural Material	0.9360 BTU/(h-ft ² .°F	
Thermal F	Resistance (R)	Specifies a material for the structure of the element. Click the	1.0684 (h-ft ² -*F)/BTU	J
Thermal r	mass	value box to open the Material Browser.	6.4712 BTU/°F	
Absorpta	nce		0.700000	
Roughne	55		3	
Identity I	Data			\$
Tune Ima	ao.		1	1
<< Prev	righter (OK Cancel	Apply

Modifying Structural Materials


If we go up to the Construction category, there is a parameter for Structure that can be edited. Select Edit to proceed to the assembly options. Here we can see the material for our Common Brick. This material can be replaced by clicking the small box located to the right of the material name. Replace the Common Brick with the modified version we created in the previous step or any other desired material with similar properties.

it Assem	nbly							
amily:		Basic Wal						
'amiy: Type:		Generic - 4" Brick						
Total thid	kness:	0' 4"				Sa	mple Height: 20' 0"	
Resistanc	ce (R):	1.0684 (h·ft²·ºF)/BTU						_
Thermal N	Mass:	6.4712 BTU/%						
Layers				EXTER	RIOR SIDE			
		Function		Material	Thickness	Wraps	Structural Material	T
	Core Bou		Layers Abov		0' 0"			
	Structure	[1]	Light Comm	non Brick	0' 4"		\checkmark	
3 Core Boundary								
5	Core Bou	ndary	Layers Below		0. 0.			
		INTERIOR	SIDE	w Wrap	0. 0.			
	Core Bou	-			0. 0.			
Ir	insert t Wrapping	INTERIOR Delete	SIDE Up	w Wrap	0. 0.			
In Default At Inse	insert t Wrapping erts:	INTERIOR Delete	SIDE Up At Ends:	w Wrap Down	0. 0.			
Ir	insert t Wrapping erts:	INTERIOR Delete	SIDE Up	w Wrap	0. 0.			
Ir Default At Inse Do not	insert t Wrapping erts: t wrap	INTERIOR Delete	SIDE Up At Ends: None	w Wrap Down	0. 0.			
Ir Default At Inse Do not Modify	insert t Wrapping erts: t wrap	INTERIOR Delete	At Ends: None only)	w Wrap Down	0. 0.			
II Default At Insei Do not Modify	insert t Wrapping erts: t wrap Vertical Stru	INTERIOR Delete	SIDE Up At Ends: None only)	w Wrap Down	0. 0.			1

After making the desired changes in the Assembly menu, select OK to exit back to the Properties window. Select OK again to apply the material and update the model. If you don't see the texture map on the wall, make sure your Visual Style is set to Realistic on the bottom toolbar in Revit.

Modifying Structural Materials


After making the desired changes in the Assembly menu, select OK to exit back to the Properties window. Select OK again to apply the material and update the model. If you don't see the texture map on the wall, make sure your Visual Style is set to Realistic on the bottom toolbar in Revit.



Modifying Family Materials


Modifying various materials within a family component

In this chapter, we will look at modifying all the materials within a family. For example, say we have a chair that fits our design stylistically but needs some change in materiality. Most properly created families should contain Type Parameters for Materials and Finishes for all the separate parts of the assembly that make up the family object(s). This makes it extremely easy to modify all the materials on-the-go without having to open up the family and modify it outside of your project file.



Modifying Family Materials


In the screenshot on the previous page, we see this particular chair has material properties for both the seat/back and tube framing. Simply click on the material value you want to replace to open the material menu.



Global Parameters

Assigning/modifying global parameter materials


In Revit, when we are working with the same value over and over again, we will assign that value to a new Global Parameter. This gives us greater control over all the objects that are referencing that Global Parameter. For example, maybe we have a curtain wall system that has several components in the assembly, but they are all the same material. By creating a new Global Variable bound to the common material, we can easily modify all the components colors in a single move.



Parameter	Value	F
Materials and Finishe		
Frame Material	Metal - Paint Finish - Dark Gray, I	Matte =
<		
🥒 🛅 🎦 🕇 🖉		Show

Global Parameters

Global Variables can be created and modified in the main tool ribbon under the Manage tab. Global Variable materials can be assigned just like a regular material, except you must select the small grey box next to the material value to open the Associate Global Parameter options. Below we assign our Frame Metal Global Parameter to the door handle to be consistent with the curtain wall.



Lighting

How do Revit lights translate into Revit Live?

Most lighting types will translate directly into your Revit Live scene without any special preparation while the project is processed in the cloud after being exported from Revit.



By default, lights in Revit Live will only display at night. However, this setting can be modified in the Lights menu found in the Settings. You have the options to keep lighting automatic, always on, or always off. Turning off the lights will help improve the performance of Revit Live.



Exporting from Revit to Revit Live

Exporting Revit models and views to Revit Live

To export your Revit model, navigate to the Add-Ins tab in the main Revit tool ribbon. Select the Go Live icon to begin the process. A new window will appear allowing users to choose a scene destination as well as the option to extend the terrain to the horizon in Revit Live. Select Save and Go to send the project to the cloud service.

	> 🔒 🕥 •	ର • ୷	• 🗁 • 🖈 10	A @ • •	£ 😪				Autode	esk Revit 20	17 - STUDEN	T VERSIO
1.0	Architecture	Structure	Systems Ins	ert Annotate	Analyze	Massing & Site	Collabora	te View	Manage	Add-Ins	Modify	-
G	0			RFR	F	0						
Modify	Go LIVE		lash Equipment point Properties	Convert RFA to Formlt 360	About For	mlt 360						
Select 👻	LIVE Design	E	3IM 360	Formlt 36	0 Converter							
							r.					- ×
🔘 Go Ll'	VE				×							- ^
Project	: Project3					9 JOBS LEF	T IN YOUR TH	RIAL			SUBSCRIBE N	wo
View:	(3D)				0	Project: View:	sample_proje {3D}	ct				0
0	Ready to G Send your Revit		todesk LIVE service.					प		୍		
▼ Ad	vanced Option	s					T	Ā	X	¥)	_	
	xtend terrain to h	orizon				UP	OADING	WAITING	PREPA	RING	OWNLOADING	
	nioad to: ;ers\Keith\Docum	ents\Autodesk	LIVE	E	Browse		Download	ing your LIVE r	model. 23 M	IB / 49 MB (47%)	
				Sa	ve and Go!						Ca	incel

Exporting from Revit to Revit Live

CHAPTER 9


Once the cloud has processed your Revit Live scene, locate the Revit Live scene in the location you specified earlier. This project can now be opened using the Revit Live Editor or Viewer. The first time you open a new Revit Live project, it is a two-step process to unpack and prepare the new scene.




Viewing Models in VR

Experience your Revit models in virtual reality (VR)

Revit Live also supports VR. Supported headsets include HTC Vive and Oculus Rift. Enabling VR can be done in a single click within Revit Live.



Located in the bottom right corner of Revit Live, you will notice a VR icon. Simply click this to launch your local VR hardware.



Conclusion

Thank you for your interest in Autodesk Revit Live. If you require additional support, please be sure to leverage the following resources:

- <u>Product Center</u>: Learn about product features, workflows, and system requirements.
- **Revit Live Forum:** Share your product knowledge, ask questions, and explore popular topics.
- <u>Autodesk Knowledge Network</u>: Find articles and engage with an expanded group of Autodesk customers who are using a broad set of Autodesk solutions.



Autodesk and the Autodesk logo, are registered trademarks or trademarks of Autodesk, Inc., and/or its subsidiaries and/or affiliates in the USA and/or other countries. All other brand names, product names, or trademarks belong to their respective holders.

Autodesk reserves the right to alter product and services offerings, and specifications and pricing at any time without notice, and is not responsible for typographical or graphical errors that may appear in this document. © 2017 Autodesk, Inc. All rights reserved.

CHAPTER 11